

QUICK START GUIDE

The Revolver

JFET BOOSTER/DRIVER

POW :

THE LEFT "POW" IS THE FIRST JFET BOOSTER IN THE SIGNAL PATH. CONSIDER IT AS YOUR PRE GAIN.

POW :

THE RIGHT "POW" IS THE SECOND JFET BOOSTER IN THE SIGNAL PATH. CONSIDER IT AS YOUR POST GAIN.



BANG:

IF YOU DRIVE THE POWS VERY HARD, YOU'RE GONNA NEED SOME HELP TO GET BACK TO UNITY GAIN. THAT'S WHEN THE "BANG" KNOB WILL BE YOUR FRIEND.

THINK OF IT AS A MASTER VOLUME.

RECOMMANDATIONS:

- EXPERIMENT BY CRANKING PRE AND/OR POST GAIN.
- GET HIGH LEVEL OF DISTORTION AT UNITY GAIN
- USE IT AS A CLEAN BOOST OR AS AN OVERDRIVE
- NEVER POINT IT AT PEOPLE !
- BE AWARE OF THAT WOLF !

*** 9V ADAPTER REQUIRED (REGULAR CENTER NEGATIVE)**